

# INSPECTION DOOR

## Assembly instructions

1. Remove the door from the frame and wall in (plaster, screw) the frame itself into the prepared opening.

2. Using the stoppers, attach the door to one side of the frame.

3. Open the latches as far as they will go and close the door to the frame. Then, swing the latches to align them with the door.

### Adjustment options

A. Perfect closing of the door at the bottom can be achieved by adjusting the sliding stops.

B. Perfect closing of the door at the top can be achieved by adjusting the pressure of the latches using the Allen screw.

4. The door can be supplemented and secured with a lamella lock.